
How to Set Up Scan to Folder on Ricoh MFD IMC Series

Follow these instructions for set up of Scan to Folder *after* a folder has been created on the network that the Ricoh MFD has privileges to scan to.

At the Home Screen select Address Book Management icon.



Press Register button.



On the first tab fill in folder name next to the Name field.

Input the Name of the folder to scan to i.e.: "Ricoh Scan Folder"



For **Protocol** leave as <u>SMB</u>




Press Browse Network icon

Select the group that the destination computer belongs

Browse the domain/work group name

Select the computer that has the scan folder

Select the shared folder on the destination computer.



Press Specify Other Auth Information in Folder Authentication Info



Insert User_Name into the Login User Name field.

Enter the username that is used to login onto the computer that the MFD will be scanning to.

Insert Password into the Login Password field.

Reenter Password in confirmation

IF YOU CANNOT BROWSE NETWORK

Folder:	Cancel	OK
Protocot	SIVIB (Send to Shared Folder on P	· ·
	Enter the path in the format [\\Computer Name (or IP Address)\Shared Folder Name].	
Path * Required	Touch to Enter	<0/256>
		Browse Network
Folder Authentication Info	Same as Administrator's Settings	•
		Connection Test

Enter the destination into the Path field


Use the following parameters

\\Computer Name\folder\sub folder\"Destination Folder"

or

\\IP Address\folder\sub folder\"Destination Folder"

Once entered completed press Connection Test



When a message indicating that "Connection has been successfully established" appears press OK Exit Address Book